



Main Board Wiring Diagram – 4 Solenoid



SW1	Position Marker/Jobbing
SW2	Home
SW3	Away
SW4	Remote Park
SW5	Collision Switch
SW6	Remote Auto Start Switch
SW7	Remote Home Switch
SW8	Remote Away Switch
IN1/IN2/GRD/+NRV	Proximity Sensor



- Blue
- Blue w/ black stripe
- Blue w/ white stripe
- Orange
- Orange w/ black stripe
- Green
- Green w/ black stripe
- White
- White w/ black stripe
- Black
- Black w/ black stripe

- Green w/ white stripe
- Red w/ black stripe
- Red
- Red w/ white stripe

Jump/bridge (collision)

- Remote start – enviro. control (dry contact)
- Walk switch - home
- Walk switch - common
- Walk switch - away